




LOWER OVEN PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)

27" BUILT-IN ELECTRIC
DOUBLE OVEN
STD-CLEAN LOWER
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8


(Black) (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			7	4455189	Top, Chassis	37	4451354	Fuse—Thermal
			9	4452159	Tube, Vent		4449809	Screw
				4159450	Screw	43	4451397	Base, Chassis
			10	4451664	Fan & Bracket Assy.		4449154	Screw
				4449809	Screw	49	4448933	Retainer, Gasket
1	LIT4450410	Literature Parts Installation Instructions	11	4452368	Oven Light Assy		4449154	Screw
	LIT4450568	Use & Care Guide	12	4452166	Bulb, Light	50	4451747	Cover, Back
	LIT4451887	Tech Sheet	13	4452165	Lens, Light		4449809	Screw
	LIT3191638	Safe Cooking Tips		4449809	Screw	51		Trim, Bottom
2		Trim, Side	14	4451739	Frame, Front		4448475	Black Model
	4450850	RH Black		4449040	Screw		4448476	White Model
	4450851	RH White		4450118	Nut		4452414	Biscuit Model
	4452122	RH Biscuit	15	4450492	Gasket, Door		4159465	Screw
	4450853	LH Black	19	4451477	Support, Insulation	53	4449845	Support, Bracket
	4450854	LH White	25	4454691	Side, Chassis (R.H. & L.H.)		4449809	Screw
	4452123	LH Biscuit Screw		4449809	Screw	FOLLOWING PARTS NOT ILLUSTRATED		
	4449747	Black Model	26	4452233	Back, Chassis			
	4449041	White		4449809	Screw	INSULATION		
3		Receiver, Hinge	27		Liner, Oven (Not serviceable)			
	4454664	Left Hand	29	4451665	Sensor		4449315	Insulation, Wrap
	4454665	Right Hand		4449154	Screw		4450364	Insulation, Back
4	4448520	Bumper, Door						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			19	4451477	Support, Insulation	37	4451442	Thermostat (TOD) (Temp.) SPST
				4449809	Screw		4449809	Screw
			20	4451605	Cap, Spacer	43	4451397	Base, Chassis
			21		Rail, Side		4449809	Screw
				4450581	Right Side	49	4448933	Retainer, Gasket
				4450582	Left Side		4449154	Screw
				4448444	Grommet	50	4451747	Cover, Back
				4449154	Screw		4449809	Screw
1		Reciever, Hinge	24	4451896	Latch Assy	53	4449845	Support, Bracket
	4454664	Left Hand		4449809	Screw		4449809	Screw
	4454665	Right Hand			(R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
4	4448520	Bumper, Door	25	4454691	Side, Chassis	INSULATION		
5	4452312	Switch, Micro		4449809	Screw			
6	4452224	Solenoid	26	4452233	Back, Chassis			
7	4451426	Switch, Micro		4449809	Screw			
8	4451537	Spring, Latch	27		Liner, Oven			
9	4452158	Tube, Vent			(Not serviceable)			
10	4452165	Lens, Light	29	4451665	Sensor			
	4159450	Screw		4449154	Screw		4449315	Insulation, Wrap
11	4452368	Oven Light Assy	34	4452266	Vent, Center		4450364	Insulation, Back
12	4452166	Bulb, Light						
14	4451739	Frame, Front						
	4449040	Screw						
15	4455381	Gasket, Door						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN DOOR PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8

(Black) (Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4451718	Door Liner
3	4449253	Glass, Inner
5	4451670	Retainer, Glass
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
6	4454945	Hinge, Door
	4449743	Screw
12	4452062	Black Model
	4452063	White Model
13	4448405	Door Handle
	4448405	Black Model
	8300257	Biscuit Model
	4448406	White Model


Illus. No.	Part No.	DESCRIPTION
14	4450813	Bracket, Handle
	4451040	Screw
	8300255	Biscuit Model
21	4451673	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8

(Black) (Designer White) (Biscuit)



Illus. No. Part No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1 4451718 Door Liner
 2 4454946 Hinge, Door
 4449743 Screw
 3 4449253 Glass, Inner
 4 4451721 Insulation, Door

Illus. No. Part No. DESCRIPTION

5 4451670 Retainer, Glass
 4449809 Screw
 7 4449257 Glass, Inner
 12 4452062 Black Model
 4452063 White Model
 13 4448405 Black Model
 8300257 Biscuit Model
 4448406 White Model
 14 4450813 Bracket, Handle
 4451040 Screw
 8300255 Biscuit Model


Illus. No. Part No. DESCRIPTION

19 4450361 Shield, Heat
 4449809 Screw
 20 4451668 Retainer, Glass
 4449809 Screw
 21 4451673 Seal, Door Top
 23 4450863 Black Model
 4450864 White Model
 4452119 Biscuit Model
 24 4455256 Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	Control Panel Assy. W/Membrane Switch
	4451967 Black Model
	4451968 White Model
	8300531 Biscuit Model
	4159465 Screw
2	4451033 Gasket, Control Panel
3	4451991 Microcomputer
	4449745 Screw
	4449899 Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	4451759	Vent, Exhaust
	4449040	Screw
2	4455334	Blower, 60MM
	4455352	Bracket, Blower
3	4451758	Foam, Block
4	4455178	Elbow, Vent-Top
5	4455177	Elbow, Vent-Bottom
6	4451789	Plate, Mounting

Illus. No.	Part No.	DESCRIPTION
7	4451891	Transformer, Control
11	4449868	Block, Terminal
	3400016	Screw
13	4448548	Vent, (Control Panel)
	4450038	Screw
14	4451597	Right
	4451598	Left
	4449809	Screw
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
	112432	Nut
18	4452366	Cover, Top Front
	4449809	Screw
19	4454943	Plate, Mounting Fan
20	4451985	Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RBD275PDB8, RBD275PDQ8, RBD276PDT8
(Black) (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

	4455350	Harness, Wire (Main)
	4450953	Conduit, Double
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4450814	Fuse Assy (Service Only)
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4451761	Support, Wiring

Miscellaneous

	814381	Hinge Pin Kit
	4448950	Screw, Install (4)